


## Smoke Detector Lost Its Mind?

*Beep.Beep.Beep..... Beep.Beep.Beep*

It May Need to be Cleaned!



**Accumulated dust may cause detector to give **triple-beep** false alarms.** If they recur, clean detector.

### Notes:

- Below steps are representative. See detector manufacturer's information/website for more information.
- During following steps detector may sound.

More info: [www.alicantehoa.com](http://www.alicantehoa.com) → Owner Services → OMC Bulletins

[www.vivoportal.com](http://www.vivoportal.com) → Documents → Association Documents → OMC Bulletins

# Alicante

classic, comfortable, modern  
in Bankers Hill

1. Turn-off power to smoke detector at circuit breaker panel.
2. Rotate detector counter-clockwise to disconnect from base.
3. Carefully unplug connector from back of detector.
4. Use vacuum cleaner to remove dust from detector exterior.
5. Open battery compartment, use computer cleaner to blow dust from detector interior.
6. Insert plug into detector and re-install detector to base.
7. Restore power to detector at circuit breaker.
8. **If false alarms persists, replace detector.**
9. If you prefer, contact an electrician to perform cleaning. You may want to choose one of the following:
  - Sommer Electric 760-315-2226
  - Service Electric 760-291-1302

